


Quad Monitor Desk Mount

Instruction Manual



SKU: STAND-V104A



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-v104a

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST











If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



TIPOVER WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM TIPOVER. TO HELP PREVENT TIPOVER:

- NEVER ALLOW CHILDREN TO CLIMB, STAND, HANG, OR PLAY ON ANY PART OF MONITOR OR STAND.
- USE TIPOVER RESTRAINT OR ANCHOR STAND TO WALL

USE OF TIPOVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE RISK OF TIPOVER.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.



DO NOT EXCEED WEIGHT CAPACITY. Failure to do so may result in serious injury.

PER ARM

TOOLS NEEDED





PACKAGE CONTENTS



A (x1) Pole



Monitor Arm



K (x2) Spare Cap



B (x1) Clamp



G (x1)



Mount



L (x4) Plastic Spacer



C (x1) Clamp Brace





Support Plate



M (x4) Cable Clip



D (x1) Decorative Cover



I(x1) Foam Pad



Side **VESA Plate**



E (x1) Center Monitor Arm



J (x4) Monitor Arm Cover



O(x2) Center **VESA Plate**



S-A (x2) M10x47mm Screw



S-F (x2) Nut



M-B (x16) M4x30mm Screw



T-D (x1) Wrench



S-B (x1) M10x100mm Screw







M-C (x16) M4 Spacer



S-C (x3) M6x10mm Screw



S-H (x1) Spring Washer



T-A (x1) 3mm Allen Wrench



S-D (x2) M10x15mm Screw



S-I (x1) M10 Washer



T-B (x1) 5mm Allen Wrench



S-E (x4) M8x10mm Screw








T-C (x1) 6mm Allen Wrench

NOTE: SOME HARDWARE INCLUDED MAY NOT BE USED


ASSEMBLY STEPS

STEP 1 - Clamp Installation

Install Pole (A) to Clamp Brace (C) using M6x10mm Screws (S-C) and a Phillips screwdriver.




Assemble Clamp (B) to Clamp Brace (C) using M10x15mm Screws (S-D) and 6mm Allen Wrench (T-B). Secure the clamp assembly to the desktop be tightening to the hand bolts on Clamp (B). Install the Pole Cover (D) to Pole (A).




STEP 1 - Grommet Installation

Remove adhesive backing from Foam Pad Pad (I) and place on the bottom of Pole (A).




Install Pole (A) to existing grommet hole using Support Plate (H) with M10x100mm Screw (S-B), M10 Washer (S-I) and Spring Washer (S-H). Tighten with Wrench (T-D). Install the Pole Cover (D) to Pole (A).




If no grommet hole exists, drill a 3/8" (10mm) diameter hole through the mounting surface.

Lay Monitor Arm **(F)** on flat surface with holes for cable clips facing down. Add Plastic Spacers **(L)** to holes at ends of Monitor Arm **(F)**.




NOTE: Transparent monitor arm image used to show cable clip holes. Holes are on the underside of arms and are not visable when arm is facing upright.


Align Monitor Arm and Center Monitor Arm (**E,F**) so that the holes for the cable clips are facing down. Insert Monitor Arms (**F**) into Center Monitor Arm (**F**) as shown below. Secure using M10x47mm Screws (**S-A**) and 6mm Allen Wrench (**T-C**).



clip holes. Holes are on the underside of arms and are not visable when arm is facing upright.


Press Monitor Arm Covers (J) onto the top and bottom of arm joints. Place Cable Clips (M) into wire clip holes.






STEP 4a - Flat Back Monitors

Attach the Center VESA Plates (**P**) to the monitors you intend to mount in the center of the mount. Attach Side VESA Plates (**0**) to remaining monitors. Secure using M4x12mm Screws (**M-A**).









Side VESA Plate (O) Installation

NOTE: Hand tighten screws to avoid stripping the plastic screw heads.

STEP 4b - Curved/Recessed Back Monitors

Attach the Center VESA Plates (**0**) to the monitors you intend to mount in the center of the mount. Attach Side VESA Plates (**N**) to remaining monitors. Secure using M4 Spacers (**M-C**), M4x30mm Screws (**M-B**) and a Phillips screwdriver.







Center VESA Plate (O) Installation

Side VESA Plate (N) Installation


STEP 5




STEP 6




Adjust Monitor Tilt



Adjust Monitor Height



Cable Management





Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S



www.vivo-us.com Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr