


Quad Monitor Desk Mount

Instruction Manual



SKU: STAND-V104Y



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-v104y

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST







www.vivo-us.com Chat live with an agent!



309-278-5303

NARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please call a qualified technician. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.



TIPOVER WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM TIPOVER. TO HELP PREVENT TIPOVER:


- NEVER ALLOW CHILDREN TO CLIMB, STAND, HANG, OR PLAY ON ANY PART OF MONITOR OR STAND.
- USE TIPOVER RESTRAINT OR ANCHOR STAND TO WALL

USE OF TIPOVER RESTRAINTS MAY ONLY REDUCE, BUT NOT ELIMINATE RISK OF TIPOVER.



WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REOUIRED.



TOOLS NEEDED



NOTE: SOME HARDWARE INCLUDED MAY NOT BE USED

DO NOT EXCEED WEIGHT CAPACITY.
Failure to do so may result in serious injury.




ASSEMBLY STEPS

STEP 1

OPTION A: Clamp Installation

Attach clamp (B) to the upper or lower holes of the clamp brace (A) using M6x10 flat head bolts (F), and tighten using the 4mm Allen wrench (H). Attach the pole (D) to the clamp brace using M6x16 flat head bolts (G). Tighten using the 4mm Allen wrench. Attach the assembled clamp to your desktop.




OPTION B: Grommet Installation


Remove the screw in the top of the hand bolt on the clamp (**B**) and remove the hand bolt from the clamp. Stick soft pads (**L**) to the bottom of the grommet base (**J**). Place the grommet base and pole (**D**) over the grommet hole in the desktop, making sure the pin on the base is aligned with the small hole in the pole. Place the support plate (**K**) onto the hand bolt, and screw in from underneath to secure the base and pole to the grommet hole.




NOTE: If desk does not have an existing grommet hole where needed, drill a hole using a 3/8" (10mm) hit




STEP 2




STEP 3






STEP 5



Adjust as Desired





Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

 \subseteq

help@vivo-us.com

AVG. RESPONSE TIME (within office hrs): 1HR 8M

- 23% within < 15m
- 38% within < 30m
- 61% within < 1hr
- 83% within < 2hr
- 92% within < 3hr



www.vivo-us.com
Chat live with an agent!

AVG. RESOLUTION TIME (within office hrs): < 15 M



309-278-5303

AVG. RESOLUTION TIME (within office hrs): 5M 4S