


Dual Ultrawide Vertical Monitor Desk Mount Instruction Manual



SKU: STAND-V200R



Scan the QR code with your mobile device or follow the link for helpful videos and specifications related to this product.

https://vivo-us.com/products/stand-v200r

GET IN TOUCH | Monday-Friday from 7:00am-7:00pm CST



help@vivo-us.com



www.vivo-us.com Chat live with an agent!



309-278-5303

🔨 WARNING!

If you do not understand these directions, or if you have any doubts about the safety of the installation, please contact our product support team at 309-278-5303 or help@vivo-us.com for further assistance. Check carefully to make sure there are no missing or defective parts. Improper installation may cause damage or serious injury. Do not use this product for any purpose that is not explicitly specified in this manual. Do not exceed weight capacity. We cannot be liable for damage or injury caused by improper mounting, incorrect assembly or inappropriate use.

🕂 WARNING: CHOKING HAZARD

SMALL PARTS - NOT FOR CHILDREN UNDER 3 YEARS. ADULT SUPERVISION IS REQUIRED.





A(x2) $B(x2)$ $C(x1)$ $D(x1)$ VESA PlateVESA Bracket $C(x1)$ Lower Pole $E(x1)$ $F(x1)$ $G(x2)$ $H(x1)$ Upper PolePole CapCable ClipGrommet Plate $I(x5)$ $J(x1)$ $Support Plate$ $M-A(x8)$ $M-B(x8)$ $M-C(x8)$ S-A(x3)S-B(x2) $M-A(x8)$ $M-A(x8)$ $M-E(x8)$ $M-C(x8)$ Mox16mmM6x10mmM4x12mmM4x16mmM5x12mm $M-D(x8)$ $M-E(x8)$ $M-F(x8)$ $T-A(x1)$ $T-B(x1)$			(†		9
E (x1) F (x1) G (x2) Upper Pole Pole Cap Cable Clip I (x5) J (x1) Pad J (x1) S-A (x3) S-B (x2) M-A (x8) M6x16mm M6x10mm M4x12mm M6x10mm Moscrew Screw Image: Construction of the second se					
Upper Pole Pole Cap Cable Clip Grommet Plate I (x5) Pad J (x1) Support Plate Image: Cable Clip Grommet Plate I (x5) Pad J (x1) Support Plate Image: Cable Clip Image: Cable Clip I (x5) Pad J (x1) Support Plate Image: Cable Clip Image: Cable Clip I (x5) Pad J (x1) Support Plate Image: Cable Clip Image: Cable Clip I (x5) Pad J (x1) Support Plate Image: Cable Clip Image: Cable Clip I (x5) M6x10mm J (x1) Support Plate Image: Cable Clip Image: Cable Clip I (x5) M6x10mm J (x1) M6x10mm Image: Cable Clip Image: Cable Clip I (x5) M6x10mm S-B (x2) M6x10mm Image: Cable Clip Image: Cable Clip I (x5) M6x10mm S-B (x2) M6x10mm Image: Cable Clip Image: Cable Clip I (x5) M6x10mm M-A (x8) M4x12mm M-B (x8) M4x12mm M-C (x8) M5x12mm I (x5) M6x10mm Image: Cable Clip Image: Cable Clip Image: Cable Clip I (x5) M6x10mm S-B (x2) M6x10mm Image: Cable Clip Image: Cable Clip I (x5) M6x10mm S-B (x2) M6x10mm Image: Cable Clip Image: Cable Clip I (x5) M6x10mm Image: Cable Clip Image: Cable Clip Image: Cable Clip I (x5) M6x10mm I	E (v1))	6 (12)	
I (x5) Pad Support Plate J (x1) Support Plate J S-A (x3) S-B (x2) M6x10mm Screw Thumbscrew Screw M4x12mm M4x12mm Screw Screw Screw Screw Screw Screw					
Pad Support Plate Image: S-A (x3) S-B (x2) M-A (x8) M-B (x8) M-C (x8) M6x16mm M6x10mm M4x12mm M4x16mm M5x12mm Image: Screw Screw Screw Screw Screw Image: Open colspan="2">Open colspan="2" Open colspan="2">Open colspan="2" Open colspan="2" Open colspan="2" Open colspan="2" Open colspan="2">Open colspan="2" Open colspan="2" Open colspan="2" Open colspan="2" Open colspan="2" Open colspan="2" Open colspan="2"	0	0	\supset		
S-A (x3) S-B (x2) M-A (x8) M-B (x8) M-C (x8) M6x16mm M6x10mm M4x12mm M4x16mm M5x12mm Screw Thumbscrew Screw Screw Screw					
M6x16mm M6x10mm M4x12mm M4x12mm M4x16mm M5x12mm Screw Screw Screw Screw Screw Screw	θ				
	M6x16mm	M6x10mm	M4x12mm	M4x16mm	M5x12mm
M-D (x8) M-E (x8) M-F (x8) T-A (x1) T-B (x1)		\bigcirc	\bigcirc		
		M-E (x8) M5 Washer	M-F (x8) Spacer		T-B (x1) Long 6mm Allen Wrench

TOOLS NEEDED




NOTE: SOME HARDWARE MAY NOT BE USED

ASSEMBLY STEPS


STEP 1a - Clamp Installation

Install Lower Pole (**D**) to Clamp (**C**) using M6x16mm Screws (**S-A**) and 4mm Allen Wrench (**T-A**). Remove protective film from Pads (**I**) and apply them to Clamp (**C**) as shown.




STEP 1b - Grommet Installation


Remove the Screw **(C1)** from the Clamp Bolt **(C2)** and remove the Clamp Bolt from Clamp **(C)**.




Remove protective film from Pads (I) and apply them to the bottom side of Grommet Plate (H).




Align the pin on top of Grommet Plate (**H**) with the small hole on the bottom of Lower Pole (**D**) and position the parts over the grommet hole. Attach to the desktop using Support Plate (**J**) and Clamp Bolt (**C2**). If there is no existing grommet hole available, drill a 13/32" (10mm) hole or larger in your desired mounting location.




STEP 2





STEP 3






STEP 5












STEP 7



WARNING



ADJUST AS DESIRED





Open Monday - Friday 7:00am - 7:00pm CST,

our dedicated support team can offer immediate assistance with rapid response times. If any parts are received damaged or defective, please contact us. We are happy to replace parts to ensure you have a fully functioning product.

Ċ	309-278-5303	AVG. RESOLUTION TIME (within office hrs): 5M 4S
<u>ر</u>	www.vivo-us.com Chat live with an agent!	AVG. RESOLUTION TIME (within office hrs): < 15 M
	help@vivo-us.com	AVG. RESPONSE TIME (within office hrs): 1HR 8M - 23% within < 15m - 38% within < 30m - 61% within < 1hr - 83% within < 2hr