Pantechnicon Steam Knob Set for Linea Mini

Installation Instructions

Thanks for your purchase of this Pantechnicon Steam Knob set for the Linea Mini!

Step 1. Remove the white plastic plug in your factory steam knob by unscrewing counterclockwise.

Step 2. Remove cotter pin from steam valve.

Step 3. Unscrew factory steam knob and catch the stack of washers before they fall on the floor and roll under your refridgerator.

Step 4. Install new knobs. Re-install stack of washers and use supplied cotter pin to fasten.

CAUTION: BE EXTREMELY CAREFUL NOT TO DENT THE SOFT ALUMINUM INTERNAL THREADS WITH YOUR PLIERS WHEN YOU ARE TRYING TO GET THE COTTER PIN BACK IN. IF YOU DENT THE THREADS THEN THE COVER PLUG WON'T THREAD IN AND YOU WILL BE SO SAD.

Step 5. Install cover plug and you are done!

Let us know if you have any comments or feedback, and go do something nice for somebody!

Best, Jacob jacob@pantechnicondesign.com