



Inground installation guide:

Items required for installation:

- Concrete Saw
- Concrete Core Drill
- Post hole digger or shovel
- Spiritlevel
- Trowel, bucket, sponge
- Concrete or concrete mix + water
- Gravel

Instructions for Installation

1. Always check for services (dial before you dig) and look at site plans
2. If there is more than one bollard mark with string line
3. If there is an existing slab, cut with a concrete saw or concrete core drill. The size of hole will be determined by size of bollard please refer to TKO DWG INSBIG01
4. Remove soil to the depth required. Fill base of hole with gravel if required.
5. Set bollard in the hole in position and place concrete in the hole, checking levels and height.
6. If bollards are in a run, work on the two outside and set up a stringline and work to heights and levels required.

TKO Bollards recommends all safety PPE be worn when installing bollards. If you have any install questions or enquiries, please call us on (07) 3421 7130 or email us at sales@tkobollards.com.au

