



P/N TWS-56

## Slider door track trim installation

The Terrawagen slider door track trim installs onto the factory end clip of the slider door track. It uses 3M VHB tape tabs to adhere to the body of the vehicle.

Make sure prior to adhering the 3M tape tabs that the ambient temperature is at least 60 degrees. You can use a hair dryer to warm the surface for optimum adhesion. Use 20 lbs of force to set tabs.

\*Clean the area of the mating surface with alcohol\*

Step 1. Gently push the tab pivot the end cap out.

Step 2. Gently pry up the lower retainer.

Step 3. pull end cap from track end.



Step 4. Separate the end cap from the track end clip

Step 5. Install end clip back into track end.

Step 6. Remove tape tabs, snap trim in place and press.

