



## Flash Bulkhead Installation

Remove the Sport housing flash plug with a flat head screwdriver and small shifting spanner. Once removed, insert the flash bulkhead ensuring the main O-Ring is in place on the base of the flash bulkhead before tightening.

To start, finger-tighten the nut onto the flash bulkhead to locate. Use the shifting spanner on the inside of the Sport Housing to hold the nut in place while using another small shifting spanner to tighten the flash bulkhead from the outside. Take care not to over tighten the flash bulkhead as this may cause damage to the O-Ring.

Once the flash bulkhead has been installed and tightened, assemble your Sport Housing with a lens port to perform a water test. Do these tests without the camera and lens inside.

1. Fill up a bathtub, use a swimming pool or hop in the ocean to test. The choice is yours just as long as you have a body of water where you can fully submerge your equipment.

2. Hold your equipment under the water for 5-10 seconds while also pressing all the buttons. Then hold the Sport Housing above your head at a tilted angle so that if there is any water inside it will gather at the bottom right back corner.

3. Repeat process for 20 seconds then 30 seconds.

For a video demonstration on how to install the flash bulkhead, please visit our website at [www.aquatech.net](http://www.aquatech.net) and view this and other helpful tips.