



**2014-2018 Ram 3500 Train Horn Mount**

877-209-8179

Sales@hornblasters.com

# **ATTENTION**

**::::::BEFORE POWDER-COATING YOUR MOUNT::::::**

**\*\*\*\*\*BEFORE INSTALLING HORNS ON YOUR MOUNT\*\*\*\*\***


**TEST FIT THE MOUNT TO THE TRUCK**

**THERE ARE VARIATIONS THAT ARE NOT COMMON, BUT ARE A  
POSSIBILITY WITH TRUCK MANUFACTURING.**

**THESE VARIATIONS MAY EFFECT HOW THE MOUNT FITS ON THE  
TRUCK.**

**HORNBLASTERS DOES NOT COVER POWDER-COATING FEES ON  
HORN MOUNTS**

# 2014-2018 Ram 3500 Train Horn




Remove spare tire  
Remove heatshield  
Remove spare tire crank assembly



Cut down half circle as far as you can  
Using a sawzall or cutoff wheel.

# 2014-2018 Ram 3500 Train Horn



-REMOVE SPARE TIRE & CRANKING MECHANISM if you haven't yet.

-Insert retainers (Plate with nuts welded to it) inside the frame in the holes that are outlined in the picture to the left.

-Line up the horn mount to match the factory holes.

-Install ½" bolts, washers and lock washers, tighten well.

**HITCH**

