



2003-2018 GM SUV Goliath Train Horn Mount

877-209-8179

Sales@hornblasters.com

# **ATTENTION**

**::::::BEFORE POWDER-COATING YOUR MOUNT::::::**

**\*\*\*\*\*BEFORE INSTALLING HORNS ON YOUR MOUNT\*\*\*\*\***

**TEST FIT THE MOUNT TO THE TRUCK**

**THERE ARE VARIATIONS THAT ARE NOT COMMON, BUT ARE A  
POSSIBILITY WITH TRUCK MANUFACTURING.**

**THESE VARIATIONS MAY EFFECT HOW THE MOUNT FITS ON THE  
TRUCK.**

**HORNBLASTERS DOES NOT COVER POWDER-COATING FEES ON  
HORN MOUNTS**

# 2003-2007 GM Tahoe-Yukon SUV



If your hitch has a U shape like this picture, use these spacers and the new ½" hardware.



These spacers are so the fittings on the horns do not contact your frame. They go in-between the hitch and the frame. Some systems like katrina, or admiral, do not require you to do this. Test before you install.

# 2007-2018 GM TAHOE/YUKON/ESCALADE



These models will bolt up with or without spacers. If you use the spacers, you must purchase new longer hardware. If you do not use the spacers, use factory hardware. Attach to the furthest three bolts near the rear bumper.



