



Tire Inflation Kit Install Guide

The Tire Inflation Kit is setup to provide an easy way to inflate your tires or other inflatables with your horn kit. Let's get started.

First, locate the two $\frac{1}{4}$ " NPT compression fittings. These fittings will be used to connect air line between the tank and air chuck.

Plumb one of these fittings into a $\frac{1}{4}$ " NPT port on the tank. Make sure to use Teflon tape or PTFE paste on the fitting so that it doesn't leak.

Remove the nut from the compression fitting and slide it over the air line. Firmly seat the air line over the barb fitting as shown to the right.

Locate the L-shaped mounting bracket that came with the inflation kit. This bracket will be used to mount the air chuck. Lay out the bracket, air chuck, and compression fitting as shown below.

