



### Mounting Instructions for

## **SUPER SPORT/TOUR TANKBAG W/SHOULDER STRAP SYSTEM**

Important:  
*READ THESE INSTRUCTIONS THOROUGHLY*

No. 1560

motorcycle, (see fig. 4)

7) Slip strap end back through the foam retainer, then lace the end of strap through buckle. (see fig. 3)

8) Now for the rear strap- remove or open motorcycle seat. (see fig. 3)

9) Thread end of remaining strap under frame tubes. Bring both ends together above the frame, making sure no that electrical wires or tubes, etc., will be pinched.

10) Re-thread straps through buckle. (see figs. 5 & 6)

11) Making sure surface of tank is clean, place tankbag on tank, clear of wires, controls or handlebars.

12) Snap front buckles to tankbag, and adjust strap length as needed.

13) Repeat step 10 for rear buckle, and snug tankbag firmly onto tank. (see fig. 7)

14) Excess strap length may be removed by cutting with a hot knife.



Fig. 5




Fig. 3



Fig. 4



Fig. 7



Fig. 6

### **MOUNTING STRAPS FOR SHOULDER USE**

Your Super Sport / Tour Tankbag becomes an impromptu backpack with the addition of the included universal straps.

1) Remove tankbag from motorcycle

2) Remove Quickclip or mounting straps from male end of quick-release connector

No other tankbag mounting system can match the versatility of your new Chase Harper Tankbag. It has been designed so that whatever type of tank you have, one of the two mounting setups included will be right for your motorcycle. Which one do you use? Easy! If the seams on your tank are easily accessed from front to back, use the Quickclips which are already attached to the bag. Simply follow the Quickclips mounting instructions. Or, if your tank seams are hard to reach because of fairings or other bodywork makes them inaccessible, use the three point system.

Note: For those who just prefer the three point system or any other combination of straps you may prefer, go ahead and use it in lieu of the Quickclips, tank seams notwithstanding.

Place tankbag on tank, locating a position that does not interfere with controls or handlebars and is compatible with your riding style.

### **TANKBAG MOUNTING INSTRUCTIONS**

#### TO MOUNT WITH QUICKCLIPS:

1) Position Quickclips on seam-edge (see fig. 1) and pull straps until a snug fit is achieved.

Note: For quick removal and replacement of tankbag, loosen and tighten straps on one side only.

2) Excess strap should now be cut, leaving about 4" beyond buckle.

Cut at a 45° angle and sear the end with a hot knife or soldering iron.




Fig. 1

#### TO MOUNT USING 3-POINT SYSTEM:

1) Find two 43" x 1" nylon webbing straps. Set them aside.

2) Disconnect the Quickclips from tankbag by pinching side release buckles.

3) Unthread Quickclip straps from buckles. Keep one buckle and Quickclip intact for reference when re-threading buckles.

4) Run one end of one 43" strap through one end of foam retainer and add buckle. (see fig. 2)

5) Place foam retainer across the very front of the tank. (see fig. 3)

6) Take loose strap end and feed it around the down tubes, directly below the steering head; make sure it doesn't interfere with cables, wires or steering the



Fig. 2

with the two straps connecting with the tankbag on the long sides (see fig. 9)

5) Put the tankbag on and adjust the straps for a comfortable fit

6) Loop the ends of the straps back through the connector to insure against strap slippage (see fig. 10)

7) Off you go!



Fig. 8



Fig. 9



Fig. 10

### **CARE AND CLEANING**

Take care to protect your Chase Harper Tankbag and straps from all sharp edges. Heavy and/or sharp objects may damage tankbag or rider. Use good judgement when loading your tankbag. Avoid hot surfaces, such as engine or exhaust pipes.

To Clean: Open all zippers, remove all inserts and hardware, set washing machine on light or regular cycle, use cold or warm water and use a mild detergent. Hang to dry.

DO NOT dry clean or put in dryer.

Touch-up cleaning may be done with spray cleaners or detergent and water.

Use a gentle spray (such as Simple Green™) for cleaning map pouch window plastic.

