



INSTRUCTIONS:

1. Align and center the diffuser underneath your bumper the way you want it to stick out.
2. With a 1/4" or less drill bit, drill the bumper through each exterior holes of the diffuser and remove the diffuser.
3. Enlarge the two holes with a 7/16" drill bit and reinstall the diffuser like the image above using bolts under the diffuser and nuts inside the bumper.
4. For a safer installation, drill your bumper through the middle of the slits in the diffuser and add the remaining hardware like picture above.

PARTS LIST (included)

	10mm bolts X 6
	Lock nuts X 6

TOOLS REQUIRED (not included)

<input type="checkbox"/> Car jack and jack stands
<input type="checkbox"/> Drill
<input type="checkbox"/> Drill bits 1/4 & 7/16
<input type="checkbox"/> Ratchet, 10mm box & key
<input type="checkbox"/> 8mm box & key