# FIXED SHOWER HEAD INSTALLATION INSTRUCTIONS

#### WHAT'S THIS FOR?

These instructions tell you how to quickly install and start enjoying your new Aqua Elegante fixed shower head. The wall-mounted shower head installs quickly and easily on any standard  $\frac{1}{2}$ " threaded shower arm (the universal size for plumbing fittings).

#### **STEP 1: PREPARE TO INSTALL**

Remove the existing shower head from the shower arm by turning counterclockwise. This can usually be done by hand, but you may need a wrench if your old shower head is on too tight. For the new shower head, make sure the black rubber screen filter is pushed all the way in.

#### **STEP 2: CLEAN THREADED PIPE**

Clean any debris that may be present on the threaded pipe. This may come in the form of old Teflon tape. Use your fingers to peel away the old tape. You can also use a paperclip to help clean the grooves between the threads to ensure a tight seal.

#### **STEP 3: WRAP NEW TEFLON TAPE**

Wrap the included Teflon tape tightly around the clean shower arm threads. 2-3 full turns around the threads is sufficient to provide coverage. You may want to cut the tape with a pair of scissors to ensure a clean break, but you can always just rip the tape with your hands instead.

#### **STEP 4: TWIST ON NEW SHOWER HEAD**

Place the new Aqua Elegante shower head on the shower arm and turn clockwise to tighten by hand. If additional tightening is needed, use a soft cloth on the nut to protect the finish and tighten with a wrench. Check for leaks and tighten again as needed. After that, get ready to enjoy!

### JOIN OUR VIP CLUB:

Do you want to save 50%, 75%, sometimes 100% off new products on Amazon? Join our free Amazon VIP List at www.AguaElegante.com/vip to receive email alerts on insane discounts. We are constantly releasing new products on Amazon that we practically give away to our VIP members. You will also receive discounts on all our existing products. The Amazon VIP Club is free to join. No purchase is required. And you can unsubscribe at any time.

## **TOOLS REQUIRED:**

- Teflon Tape (included)
- Paperclip (optional)
- Scissors (optional)
- Wrench (optional)









