

Multi Spider Net Instructions

Poles:

- 1. Take pole (A) with the flat end and take the middle pole (B).
- 2. Stick Pole (B) approximately 5 cm in pole (A).
- 3. The snap-system will fix the poles.
- 4. Take pole (C) and stick it into the combination of pole (A) and (B) = pole (D) until the snap-system locks in the first hole.
- 5. Repeat step 1-7 with the three remaining poles.

Net:

- 1. Spread the net that the white border is on top and take pole (D).
- 2. Take the screw on the bottom side of the net and pull it through the hole in pole (B). Close the screw.
- 3. Take the white string on the upper side of the net and pull it through the hole in pole (C) down to the screw in pole (B) and fix it (knot). Close the screw.
- 4. Take the screw on the upper side of the net and pull it through the hole with the white string in pole (C). Close the screw.
- 5. Repeat step 1. 4. with second pole (D).
- 6. Stretch the net and push both pole (D) into the ground.
- 7. Pull the added white storm-string through the ring of the upper screw. Fix it like a triangle with two yellow tent pegs in the ground.

	pole (A)
1. Lay an right-angled field with the red marking line.2. Fix it with silver tent pegs.	pole (B)
	pole (C)
	pole (D)
	tent peg
	buildup

