



PRIORITY BICYCLES

Please have all accessories professionally installed, or have your assembly verified by a professional bicycle mechanic.

Step 1. Take off the grip end caps with a flat head screw driver.

Step 2. On the right side, move the shifter (5mm allen) in and away from the grip.

Step 3. Remove both grips. The easiest way is to cut them off using a razor blade or other sharp object. You can try to salvage the original grips if you wish - for each grip, if you have an air compressor blow air from the inside out. Otherwise use a tool to pry up the grip then spray hair spray from the inside and work the grip with your hand back and forth. There might be some glue holding the grip to the bar, however hair spray (or compressed air) will break up the glue and allow the grips to slide off. For a video tutorial of grip removal see: <http://www.prioritybicycles.com/gripvideo>.

Step 4. Remove the shifter, then swap the old handlebar for the new and reinstall the shifter.

Step 5. Use hair spray (or an air compressor) to get the grips back onto your new handlebars. Reinstall the bar end caps. We recommend adding a little super glue underneath the grips to keep them from sliding.

Step 6. Perform a safety check. Ride your bicycle in a controlled environment to ensure that everything is tight and secure.

Questions? Contact us anytime:

- (917) 819-1665
- Info@prioritybicycles.com