
Need help! Call us on 1300 527 665







**Special Note:** No pre-drilled holes or nut inserts are provided.

Wood screws will be required to be drilled directly into underside of desk top.

2 persons required for installation

**Tools Required:** Power screwdriver.

#### **ASSEMBLY INSTRUCTIONS**

## Blackjack Executive Office Desk



**x2** 

х4

х4

х4

**x2** 

х4

M10 x 30mm


M10 x 110mm

M8 x 16mm

M5 x 30mm Self Tapping

M8 x 16mm Grub Screw


M8 x 25mm



www.jasonl.com.au

Need help! Call us on 1300 527 665






www.jasonl.com.au

Need help! Call us on 1300 527 665







www.jasonl.com.au

Need help! Call us on 1300 527 665









#### www.jasonl.com.au

#### Need help!

Call us on **1300 527 665** 








www.jasonl.com.au

Need help! Call us on


Call us on **1300 527 665** 





Need help! Call us on 1300 527 665






www.jasonl.com.au


Need help! Call us on

1300 527 665

jason.l
your office furniture mate







www.jasonl.com.au

Need help! Call us on

1300 527 665



# **Assembly** completed

