

**Special Note:** No pre-drilled holes or nut inserts are provided. Wood screws will be required to be drilled directly into underside of desk top.

**2** persons required for installation **Tools Required:** Power screwdriver.

## **ASSEMBLY INSTRUCTIONS Blackjack Executive Office L-Shaped Des**

QTY

x2

x1 x1 x1 хЗ х4 x2 х4 хЗ хЗ х6 х6 x1

QTY хЗ хЗ х8 x2 х6

хЗ

х6

w	ww.jasonl.com.au			• •
<b>e</b> (	<b>Need help!</b> Call us on		jason.l	
sk	1300 527 665		your office furniture mate	I I
			<	
	13-			
		17-		7
	3 — 16	10> 53		$\int_{\nabla}$
18 - 5				
		19	4	10
9	)		- 1	<b>15</b>
	~ 7			
				8
	o⊲—– <b>12</b>			A
20			Ø	

## Components

1	Die Cast Upper Wrist (A)
2	Die Cast Upper Wrist (B)
3	Top Rail
4	Top Rail
5	Leg-pole Tube Ø51
6	Top Rail Cap
7	Large Foot
8	Small Foot
9	Cross Connector
10	Gasket
11	Collar Plug
12	Foot Glide
13	Plastic Support
	Screws
14	M10 x 30mm
15	M8 x 25mm

16	M5 x 30mm Self Tapping
17	M5 x 20mm Self Tapping
18	M8 x 16mm Grub Screw
19	M10 x 110mm
20	M8 x 16mm



















