# How to install curtain poles

### 1. Gather the necessary tools

You will need a drill, drill bits, a level, a measuring tape, a pencil and your curtain brackets, rings and pole(s).

## 2. Install curtain pole brackets

- a. Unscrew the backing plate from the curtain pole bracket and mark the wall with a pencil where the screws need to go.
- b. Pre-drill holes, insert wall anchors. You may need to use a hammer to push the wall anchors in place, if needed. Then, screw in the backing plate.
- c. Once the backing plate is securely attached to the wall, attach the bracket by rotating it onto the plate.
- d. Decide where you would like to install the other pole bracket(s). You may want to use the measuring tape and/or a level to ensure that the brackets are going to be level.

#### 3. Install one finial

Using the Allen key provided, carefully loosen the holding screw on the finial until you can slide it onto the pole end. Once the finial is on the pole, use the Allen key to tighten the holding screw which will keep the finial securely in place.

## 4. Attach curtain rings

Decide how many curtain rings you will need. If you already have the material ready, you may want to attach the curtain rings/hooks now. Slide the curtain rings (with or without the material attached) over the curtain pole.

#### 5. Install the second finial

## 6. Install the curtain pole

Using the Allen key provided, carefully loosen the holding screws on the pole brackets to allow you to rest the curtain pole on the brackets. Once the curtain pole is attached to the brackets, you may want to tighten the holding screw to secure it into place.