

ASSEMBLING

1. Choose the combination of the parts that you wish to use and assemble the Telescopic Recoil System as shown on **Fig 1**.

Fig. 1



2. Insert **One** External Spring to the Telescopic Recoil System **Fig 2**.



3. Insert **One** Spacer in the other free coil of the External Spring to lock in the Spacer Groove **Fig 3**. The system now is ready for installation.

For questions contact the Dealer who supplied you this product or contact us at

service@dpmssystems.com

Video instructions: www.dpmssystems.com/faqs

INSTALLATION INSTRUCTIONS AK 47 PLATFORM



PARTS LIST

1. Telescopic Recoil Rod 2. Long External Spring 3. Medium External Spring
4. Short External Spring 5. Short Spacer 6. Medium Spacer 7. Long Spacer

ADJUSTABILITY SUGGESTIONS

Any combination of the springs and spacers will allow the rifle to function properly. Our suggestion for the best results is to use with a low velocity and small caliber ammunition the short-soft springs and short spacer.

For big caliber and heavy-strong ammunition we suggest to use the longer-stronger springs and the long/spacer.