

# Field Termination Plug User Guide

FPS

**1**

Copper Foil Tape  
30mm  
10mm

**2**

Boot  
Cable

**3**

10 mm  
30mm Min.  
or  
10 mm  
30mm Min.

S/FTP U/FTP.F/UTP

**4**

10 mm  
30mm Min.  
Copper Foil Tape

**5**

**6**

5-8mm Max.

**7**

Cut 2  
Cut 1  
0.2mm Max.

**8**

Align

**9a Hand screwing**

1 Close  
2 Screw

**9b Optional ETC(Easy Tool to Crimp) Tool or Suggested 14mm Size Open-end Wrench for C8 Cable if needed.**

1  
2  
3  
1  
2  
Use C8 Cable Optional  
1  
2  
Push

**10**

3.0mm Min.

	Solid	Stranded	Cable (O.D.)
C6 <sub>A</sub>	23~26AWG	23~26AWG	6.0~7.5mm

	Solid	Stranded	Cable (O.D.)
C8	22~24AWG	22~24AWG	7.0~8.5mm