



P.O. Box 1719
 Corona, CA 92878
 Support: 877-512-8111
 www.aFeFilters.com

Intake Kit Installation Instructions: 2001-2006 BMW X5 L6.

Kit Part # 51/54-10691 Magnum Force Stage-1 Intake Make: BMW	Tools Required 5/16" nut driver Flathead screwdriver	Part List: 1 Air filter part # 24-35507 Pro Dry S™ 21-35507 1 Housing powder coat black wrinkle part 1 Coupling straight 3.5" x2" 2 Clamps #056 (3 1/16" - 4) 30 Trim seal 7/16" bulb	
Model: X5 Year: 01-06 Engine: L6-3.0L			
Note: Please confirm Parts List and read all instructions steps before proceeding with actual installation.			



Complete kit with parts.



Complete stock intake.



Disconnect negative post from battery terminal. Unclip the (2) spring clips that secure the MAF sensor to the air box.



Unclip the (4) spring clips located around the air box by pulling back on the clip



Separate the top portion of the air box from the MAF sensor by pulling straight up and out.



Insert the new AFE air filter housing into the lower portion of the OEM air box. Make sure the housing is placed inside the groove of the OEM box. Fasten the (4) spring clips into the new housing



Place the rubber coupler between the MAF sensor and the intake pipe and slip the (2) #56 hose clamps over the connection and tighten the hose clamps.



Install the pre-oiled filter in the housing and tighten down clamp. DO-NOT use any oil or grease. Install the housing trim seal around the sides of the housing.



Place enclosed CARB EO sticker on or near the device on a smooth, clean surface. EO identification label is required to pass the smog inspection. Your installation is now complete. Make sure all hoses and clamps are tight and that all electrical components are secure. Check and retighten connections and filter after a few hours of operation. Close hood slowly to verify hood clearance