

## T Corkscrew Kit Instructions

### You will need:

Drill bits: 29/64"

Corkscrew Bushing

**Drill, Tube & Square your blanks & mount on your mandrel**



**Turn your blank down to the bushings. Polish & finish blank**

**Lay out your parts based on the diagram below**



### Assembling the pen

1. Press the coupler into one end of the tube.
2. Press the end cap into the other end of the tube.
3. Screw thread into the head.
4. Screw the head assembly into the coupler.