Fusion Razor Kit Instructions

You will need:

Drill bits: 7mm Razor Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank Lay out your parts based on the diagram below



- 1. Thread the rod into the end cap.
- 2. Slide your blank over the threaded rod and thread the head coupler assembly onto the threaded rop.
- 3. Thread the Fusion head onto the head coupler until snug