

Letter Opener #10 Kit Instructions

You will need:

Drill bits: 7.5mm

Letter Opener #10 Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank

Lay out your parts based on the diagram below



Assembly

1. Press the end cap into tube.
2. Press the center band into opposite end.
3. Put the retainer into the brass tube, making sure the chamfered end is against the tube.
4. Pass the tang of the blade through the coupler and screw into the thread retainer handle.
5. Optional- you can use a drop of CA glue on all mating parts to ensure a permanent joint.