# Letter Opener #11 Kit Instructions


You will need: Drill bits: 7mm Letter Opener #11 Bushing

### Drill, Tube & Square your blanks & mount on your mandrel



#### Turn your blank down to the bushings. Polish & finish blank

## Lay out your parts based on the diagram below



#### Assembly

- 1. Press the center coupler, stepped end first, into one end of the tube.
- 2. Press the cap into the other end of the tube.
- 3. Slide the bolster nut onto the blade, cone end first, and thread the blade/bolster nut into the center coupler.