

Mach 3 Razor Kit Instructions

You will need:

Drill bits: 7mm

Razor Bushing

Drill, Tube & Square your blanks & mount on your mandrel



Turn your blank down to the bushings. Polish & finish blank

Lay out your parts based on the diagram below



Assembling the pen

1. Press the coupler into either end of the tube.
2. Press the lower cap into the opposite end.
3. Screw the razor holder into the coupler.