

## Multi Tool Kit Instructions

### You will need:

Drill bits: 7/16"

Multi Tool Bushing

**Drill, Tube & Square your blanks & mount on your mandrel**



**Turn your blank down to the bushings. Polish & finish blank**

**Lay out your parts based on the diagram below**



### Assembly

1. Press the clip into the cap and then press into the upper end of the tube.
2. Press the tip into the other end.
3. Place the tool bit into the tip for use.
4. You screw the tip to change the tool bit you want.