

Pipe Kit Instructions

Start with a blank that is about 2 1/8" long.

That will leave enough threads on the ends for the nuts and metal parts.

Drill the blank out with a 25/64" bit (10mm is comparable) and glue it directly to the threaded tube, using the nut to hold it tight.



Put the lathe collar into the lathe chuck



When the glue on the blank is dry, screw it into the collar.



Put the tailstock in the other end and turn like that.

Like turning between centers, but the one end is held tight by the threads. No need for bushings or mandrels.



These can be turned to any size or shape you want. They don't have to be any specific diameter. Turn, sand, finish and done!
Rubber o-ring goes between the nut and elbow only on that style kit.