Threaded Project Kit Instructions

You will need:

Universal Mandrel Brass Knurled Insert ½" Drill Bit Epoxy

With no bushings:Rasp Grater, Vegetable Peeler, Honey Dipper, Coffee Scoop

With 3/4" bushings:Bottle Opener

With 13/16" bushings: Bottle Stopper, Classic Ice Cream Scoop

With 15/16" bushings: Pizza Slicer

Square Blank. Drill ½" hole for Brass Knurled Insert & Epoxy the threaded insert in blank. Once dried mount blank on Universal Mandrel with or without bushings based on kit making.



Thread Universal Mandrel to lathe. Turn your blank . Polish & finish blank Thread end onto blank.