

## 2<sup>nd</sup> Gen Tacoma RIPP Catch Can Install Instructions



1. Replace the original catch can fittings with the provided smaller diameter fittings and o-rings.
2. Use the provided 10mm nut, bolt, and washers to attach the catch can to the radiator support on the passenger side of the vehicle. There is an existing hole here.
3. Remove the factory PCV hose and keep the two spring clamps to reuse.
4. Note for steps 5 and 6 we routed both hoses underneath the throttle body and intake manifold. Extra hose length has been provided if you wish to route the hoses around the manifold instead of underneath. If routing underneath you may need to trim excess length.
5. Route the longer hose from the catch can inlet fitting to the fitting on the valve cover. Reuse factory spring clamp on the valve cover fitting and use the provided spring clamp on the catch can fitting.
6. Route the shorter hose from the bung on the intake manifold to the outlet of the catch can. Reuse factory spring clamp on the intake manifold fitting and use the provided spring clamp on the catch can fitting.

