

## 3<sup>rd</sup> Gen Tacoma RIPP Catch Can Install Instructions



1. Replace the original catch can fittings with the provided smaller diameter fittings and o-rings.
2. Remove the factory fan shroud bolt and install the RIPP Catch Can using the provided 10mm bolt. Installing the bracket first then the can to the bracket using the allen head screws is often easier. A 4mm allen wrench will be needed.
3. Remove the factory PCV hose from the intake manifold and connect the longer hose from the outlet side of the catch can to this bung. Route this hose under the wiring harness and up into the bung. Reuse factory spring clamp and use provided spring clamp on the catch can.
4. Insert the supplied 90 degree fitting into the OEM PCV hose and attach a hose clamp.
5. Connect the shorter hose from the inlet of the catch can to this 90 degree fitting. Hose clamp all ends.

