

# Nurture Soap Melt & Pour Kit Soap Making Instructions

## What You Will Need to Make Soap

- The Nurture Soap Starter Melt & Pour Kit
- Spatula for stirring
- Knife
- Large Microwave Safe Bowl
- Teaspoon
- Spray bottle with Isopropyl alcohol

## Instructions

1. Cut up two - 1 lb blocks of melt and pour soap into 1" square pieces. Place pieces in a large microwave safe bowl.
2. Place bowl in microwave. Microwave on high in 30 second intervals, stirring every 30 seconds until thoroughly melted. Be sure not to overheat.
3. When your melt and pour base is completely melted add one teaspoon (approximately half a sample bag of mica to the base. Stir thoroughly until the mica is fully incorporated.
4. Add 1 sample bottle of fragrance to the melt and pour base. Stir until thoroughly mixed.
5. Carefully pour the base into the 2 lb mold. (You may have some base left over. If you do you can pour it into a small container such as a Dixie cup).
6. If there are any air bubbles on top of your soap, spray with a small amount of alcohol to get rid of them.
7. Let the soap harden for about 6 hours.
8. Unmold your soap and carefully cut into bars with a knife.

**Congratulations! You have made melt and pour soap and it's ready to use!**