



Micro Servo Winch Mount Installation Instructions

Covers Parts #5503 (7 Slot) & 5504 (Yota)



Kit Contents:

- Micro Servo Mount (1 Piece)
- Front Grille With Metal Rope Guide (1 Piece)
- Roof Mount Rope Guide and Pulley (1 Piece)
- M2x6mm Button Head Screws (4 Pieces)
- M3x8mm Button Head Screws (4 Pieces)
- M3x25mm Button Head Screw (1 Piece)
- Duraline™ 220 Winch Line (5 foot)
- Stainless Steel Multi Hook (1 Piece)

Servo Mount Installation:

1. Mount the servo into the mount using the provided M2x6 screws as shown.
2. Install the mount into the truck using the included M3x8 button head screws into the back side of the shock towers.
3. Using a rotary tool with a cut-off disc in a straight downward motion (using the side of the cut-off disc), add a relief to the cross bar in front of the servo winch as shown for the winch spool to have clearance. Test fit and check for clearance.



4. Remove the factory front grille. Remove the LED light retainers and bulbs from the back of the grille. Then pop out the headlight lenses by inserting something through the LED bulb opening in the back of the grille.
5. Install the headlight lenses into the new grille. We suggest using a little shoe goo or E6000 on the pins before inserting to hold the lenses. CA glue can also be used, but be careful as it can fog the lenses if too much is used.
6. Install the LED bulbs and secure them with the factory retainers and screws.
7. Install the grille assembly into the truck and secure it with the factory hardware.
8. Install the winch line onto the winch spool and install the spool onto the servo winch. Run the line through the metal rope guide in the center of the grille.

Roof Rope Guide Installation:

1. Remove the center rear roof cage screw.
2. Replace it with the included roof rope guide and M3x25mm Screw as shown in the photo to the right.

