



Installation Instructions for Internal Bump Stops

OUR TRIPLE TREES KITS INCLUDE INTERNAL BUMP STOPS. THESE INSTRUCTIONS ARE DESIGNED TO AID IN THE INSTALLATION PROCESS.

NOTE: PLEASE READ ALL INSTRUCTIONS BEFORE STARTING THE TEAR-DOWN PROCESS

WARNING – INTERNAL BUMP STOPS SHOULD BE INSTALLED BY A QUALIFIED SERVICE TECHNICIAN ONLY. BAGGER BROTHERS ASSUMES NO RESPONSIBILITY FOR FALUTY INSTALLATIONS.

1. Drain the oil and disassemble forks per your H-D specific manual and clean all parts.
2. Apply a small amount of grease to the inside of the damper stop to help retain it on the damper tube prior to reassembly.
3. Slide the bump stop over the end of each damper stop (aluminum fork stop) and locate these parts on the end of the damper tube. (See picture below) **NOTE: your stop may not be the same length as the one pictured.**



4. Slide the fork tube/damper assembly in to the fork leg being sure the damper stop lines up with the pilot hole in the bottom of the fork leg.
5. After reassembly is complete, fill with fresh fork oil. We recommend a good quality 20W for added firmness and improved dampening.