NO.	03	05	10	23	27														
Quantity	4	0	2	6	N	Frame	 If you have a h clear plastic clips. 		5. You ca stand, lif	4. Its tin the print feed only the botto	3. Now s difficult v spring po	2. Make	1. Take a according	Setu					
Quantity Confirm							have a hu stic clips.	k the frar designed	an set up 't the fabi	 Its time to get your hands clear the printed fabric. Feed the fabric feed only a few feet, then stand the the bottom, now close the Zipper. 	 Now start pushing t difficult you can slightl spring pop up on place. 	sure that	 Take all the parts out of the bags according to the assembly diagram. 	Setup Instructions					
NO.	35	37	(E2)	(L2)	RZ		eader in t	nes toge tight so	the feet ric panels	your han Feed the et, then s close the	iing the p lightly tw place.	all the c	ts out of ssembly	tructi					
Quantity	6	_	2	-	<u> </u>	Frame	che kit you	To lock the frames together you can us they are designed tight so they lock well.	5. You can set up the feet in the position that stand, lift the fabric panels and fit on the feet	ds cleane e fabric fr stand the Zipper.	oipes toge vist the pa	Make sure that all the corresponding numbers are correct.	the bags diagram.	suo					
Quantity Confirm						CD	u can tix t	an use th well.	n the fee	d as now om the rc frame up	ther unti arts toget	ling num	and lay tl						
NO.	90°						the t		t you w t.	you ar und ec then :	l they f her to	oers ar	nem or						
Quantity	0					Frame	It you have a header in the kit you can fix to the top by using the ear plastic clips.	To lock the frames together you can use the "S" shaped brackets, ey are designed tight so they lock well.	You can set up the feet in the position that you want to erect the and, lift the fabric panels and fit on the feet.	4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper.	 Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place. 	e correct.	 Take all the parts out of the bags and lay them on the ground according to the assembly diagram. 						
Confirm						Û	ig the	ickets,	ect the	handle e frame, abric to	locking		h						
NO.																			
Quantit						Frame									(<u> </u>]		600	
Quantity Confirm						Φ							7				1		DL
n NO.																			B-
Quantity						Frame								_					102
/ Confirm						Û							E LI H	3 [-1020-N
NO.															(\				A
Quantity						Frame													
						ne							Æ						
Confirm															L			6	
NO.			40"	32"	22.6"		h												
Confirm						'V kit	2000E	1448mm(57")											



WATERFALL

Setup Instructions



1.Connect poles by pressing and pushing.



 Connect corner sections to straight sections with matching shape codes.



 Unzip print and lay image face up. Slide print onto frame like a pillow case.



4.Connect feet by pressing and pushing.



5. Zip the bottom edge of the graphic beyond the center point as shown above.



 6. The shelves come semi assembled, just make sure that they are level before you tighten the clamp.



7. Position frame as desired and clamp in place.



8. Enjoy.



WATERFALL

Setup Instructions



1.Connect poles by pressing and pushing.



 Connect corner sections to straight sections with matching shape codes.



 Unzip print and lay image face up. Slide print onto frame like a pillow case.



4.Connect feet by pressing and pushing.



5. Zip the bottom edge of the graphic beyond the center point as shown above.



 6. The shelves come semi assembled, just make sure that they are level before you tighten the clamp.



7. Position frame as desired and clamp in place.



8. Enjoy.







2.









