

Woodstove Chimney Installation Sequence

- Review Estimate with owner
- Identify stove location on floor
- Find flue center on ceiling with plumb bob or string and nail
- Drill through to roof or cut out drywall for support box 14 1/4" x 14 1/4"
- Add blocking and drive nail through roof decking for center mark
- Hang box with 3 screws or nails per side – plumb & square

Cutout for Flashing

- Center flashing on nail
- Draw crayon outline of inside of flashing cone then remove flashing
- Extend line 1" outside of marked outline in horseshoe shape
- Remove staples in roofing material for flashing
- Slide flashing under roofing
- Install pipe
- Secure flashing nails
- Caulk silicone seam + storm collar
- Install cap

