ASSEMBLY INSTRUCTION G5674 -2 DOOR SIDEBOARD

No	Name of Hardware	Q.ty
1	Bracket	2
2	Tie &	1
3	Screw Ø4 x 20	2

STEP 1

STEP 2





