## **ASSEMBLY INSTRUCTION** ROSELAND FURNITURE LARGE SIDEBOARD Name of Component Q.ty No O **(5)** Ø A Name of Hardware Q.ty No (1) Bracket 2 **2** Tie 1 STEP 1 Screw M4 x 20 2 Bummin Screw M4 x 35 2 **(5)** 3 (Set) Handle Ø Ø STEP 2 FINAL