



## QUICK START:

1. CLICK BUTTON 5X TO TURN ON
2. SCREW YOUR 510 CARTRIDGE ON
3. CLICK BUTTON 3X TO SELECT VOLTAGE
4. CLICK BUTTON 4X TO CHECK BATTERY %
5. CLICK BUTTON 2X FOR PREP
6. MODE TO CLEAR CARTRIDGE AIRWAY
7. PRESS BUTTON TO TAKE YOUR HIT!

### DIGITAL CONTROL FLEX TEMP

L5 4.0V

L4 3.5V

L3 3.0V

L2 2.5V

L1 2.0V



FLEX  
TEMP



BATTERY  
LIFE



DIGITAL  
SCREEN



AUTO  
OFF