

Corner Brace Kit

Rev. Date 2023-01-02

Tools

- Ladder
- Tape Measure
- Drill
- Saw
- Ratchet & Sockets

Parts (hardware included)

- 1 $\frac{3}{8}$ " Tension Band
- Flat Swage 36in Brace
- Flat Open 78in Brace
- 1 $\frac{5}{8}$ " Tension Band



Carriage bolt threads will be situated toward the inside of the hoop house.

Installation of Corner Brace

1. Insert swaged end of 36" into the 78" and connect with #8 screw. Make sure that the flats are in line with each other, before screwing together.
2. 1 $\frac{3}{8}$ " Tension bands wrap around endwall hoops and secure with bolts through tension band and hole in flat end of the brace pole.
3. 1 $\frac{5}{8}$ " Tension bands go around the third hoop's ground post and are secured with bolts through tension band and hole in the flat end of the brace pole.
4. Repeat steps for each corner.