

DOOR LATCH INSTALL

THIS STEP IS DONE AFTER PLASTIC IS ON

TOOLS

- 1/4" DRILL BIT
- 7/8" DRILL BIT
- 7/16" SOCKETS OR ADJUSTABLE WRENCH (WILL NEED TWO)
- 1/4" DRIVER FOR #8 SELF TAP

STEPS

1. DRILL A 7/8" HOLE 5" FROM DOOR EDGE AND RIGHT IN THE MIDDLE OF DOOR FRAME CENTER BRACE
2. THREAD LATCH THROUGH HOLE AND ALIGN PLATE HORIZONTALLY MARK HOLES
3. SECURE WITH PROVIDED 1/4" X 3" BOLTS, NUTS, AND BACK PLATE. USE 7/16" SOCKET/WRENCHES
4. MOUNT DOOR LATCH WITH #8 SELF TAP SCREWS AGAINST DOOR EDGE SO THAT THE LATCH LAYS FLAT
5. ATTACH MOUNTING PLATE TO DOOR FRAME (OR DOUBLE DOOR) TO ALIGN WITH FLAT LATCH BAR

