



## 2011-2016 6.7 Powerstroke External Catch Can Instructions

**\*\*\*Note:** Although this product is designed for use on the 6.7 Powerstroke it is still universal in design. This means with the included parts its possible to mount it under the truck in different configurations. We will show you our recommended way to do it.

Once installed its as simple as draining it every oil change.



1. Attach the included hose and extension to your existing CCV hose with supplied union and clamps/ties.



2. Mount the included L bracket on to the closest fuel pump bracket stud closest to the rear of the vehicle as pictured above. We prefer this location on the 11-16 Model trucks. The bracket is designed to work with the frame studs and nuts making custom locations easier to achieve.



3. Loosen the E-brake cable guide bracket flatten/straighten the locating tab with pliers and reinstall with the bolt loose so that it can be adjusted to keep the cable away from the catch can after installing it.



4. Mount the catch can and orientate the drain and hose inlets as shown. Install the catch can to the L bracket with the provided bolts and washers.



5. Install the 90 degree hose end and route the hose similar to the picture above and connect to the hose end by simply pushing it on. No clamp needed. You can now adjust the E brake guide bracket so that its not rubbing the catch can then tighten the bolt.