

ONTORK

PERFORMANCE TECHNOLOGY

Thank you for your purchase of our 6.7L PSD Injector Hold Down Kit.

This Kit Includes:

8X Hold Down Bolts
8X Hold Down Washer
1X Instructions

Instructions:

WARNING:

DO NOT OVER TORQUE OR THE THREADS IN THE HEAD WILL BE DAMAGED!

1. Apply assembly lubricant or motor oil liberally to threads of the bolts and the washer.
2. Install the washer on the bolt with the flat of the washer facing up.
3. Thread the bolt with the washer into the valve cover by hand.
4. Torque the bolt to 30 lbs-ft using a calibrated torque wrench

