



S550 GT500 Vertical link instructions

- 1. Tools Needed hydraulic jack and jack stands, Wrenches – 15mm and 18mm.**
- 2. Lift the rear of the vehicle and safely support it with jack stands.**
- 3. Using an 18mm wrench, remove the Upper bolt on the vertical link.**
- 4. Remove the Bottom bolt using a 15mm wrench. Remove the vertical link.**
- 5. Install the SPE vertical link using the factory hardware.**
- 6. Torque the Upper bolt to 129 ft/lbs and the Lower bolt to 81 ft/lbs.**

