



S550 GT Vertical link instructions

1. Tools Needed hydraulic jack and jack stands, Wrenches – 15mm and 18mm.
2. Lift the rear of the vehicle and safely support it with jack stands.
3. Using an 18mm wrench, remove the lower bolt on the vertical link.
4. Remove the top bolt using a 15mm wrench. Remove vertical link.
5. Install the SPE vertical link using the factory hardware.
6. Torque the lower bolt to 129 ft/lbs and the upper bolt to 81 ft/lbs.



