



SPE Tetrad -4AN O-ring pump Coupler Installation notes

1. Install the O ring on a Ti pump one barb down from the end of the outlet.



2. Push the billet body onto the O ring. You will have to work your way around the pump outlet with a pick or plastic thin tool to gently tuck the o ring into the coupler. After the O-ring is started, push the body down until it stops. install the C retainers with the provided bolts.



