



## INSTRUCTION FOR EAR IMPRESSION



 Impression area     Fill this area     Extend to 2nd bend

### STEP 1

Please provide this instruction to your audiologist.  
Please take the following precautions:

- Use of biting block is required for tighter fitment.
- Make sure that the impressions are extended beyond 2nd bend of ear canal (indicated as yellow).
- Make sure that the extended area (indicated as white arrow) has at least 10mm of space.
- Make sure to fill the area indicated as blue.



### STEP 2

Ship the completed ear impression along with a copy of your order confirmation to the following address.

Make sure to keep the package well protected so that the impression will not be damaged during transit.

#### **ADVANCED CIEM LAB**

ATTN : ADVSOUND-CIEM  
4140 Capitola Road, Suite R  
Capitola, CA 95010  
+1 516 734 6320