

— INSTRUCTION FOR EAR IMPRESSION —



 Impression area  Fill this area  Extend to 2nd bend

STEP 1

Please provide this instruction to your audiologist.
Please take the following precautions:

- Use of biting block is required for tighter fitment.
- Make sure that the impressions are extended beyond 2nd bend of ear canal (indicated as yellow).
- Make sure that the extended area (indicated as white arrow) has at least 10mm of space.
- Make sure to fill the area indicated as blue.



STEP 2

Ship the completed ear impression along with a copy of your order confirmation to the following address.

Make sure to keep the package well protected so that the impression will not be damaged during transit.

ADV. CIEM LAB

ATTN : ADVSOUND-CIEM
4140 Capitola Road, Suite R
Capitola, CA 95010
+1 516 734 6320