



Parcel Net

<u>Kit Contents</u>	<u>Tools Required</u>
<ul style="list-style-type: none">• 1 BMW Parcel Net• 4 Fixing Screws	<ul style="list-style-type: none">• Sheet Metal Screw and Screw Driver• Masking tape

Please read instructions thoroughly before completing installation. If you have questions or concerns, please do not hesitate to contact me.

Installation

The Fixing Screws are designed to twist in (similar to a regular screw) through the carpet on either side of the center console. The Fixing Screws attach to the metal frame of the Parcel Net and once secured to the console, hold the net in place. Included in the kit are 4 of these screws. The ideal placement of the screws on the frame of the net is to have one screw within an inch of the top of the short sides of the frame. Along the longer, bottom part of the net, should be the other 2 screws within 1 inch of the end (The corner of the frame).

Begin by placing the 4 screws in the desired position. Roughly estimate where the screws will line up on the carpet of the center console and place a section of tape at each screw point. Placing the net in the correct Up/Down and Left/Right position is subjective. The net should not be too low as a passenger's foot may have too much contact with the net and the net should not be too far toward the front of the car so that a driver cannot have easy access to it. We suggest spending as much time as you need to get the placement exactly where you think the net will be the most functional. Once you have the net in the correct position, press each of the screws into the masking tape so they make clear indications of the screw positions.

With the screw locations clearly marked, use the sheet metal screws (the screws should have a thread size that is smaller than the Fixing Screws-too big and the Fixing Screws will not work) to puncture the carpet. You should be able to thread the screws by hand but you may wish to use a screwdriver as the carpet has a good amount of backing. Once you have all 4 holes opened with the sheet metal screw, remove the masking tape and then screw in the Fixing Screws. They will sit flush with the carpet. Snap in the frame of the parcel net into each of the Fixing Screws.

Customer Satisfaction

If you like my work, please drop me a line and let me know. Tell other BMW owners. If you are not happy with my work, let me know. Let me make it right for you. -- Andy Maddux