



## Z3 & M Coupe Chrome Sunroof Surround

### **Chrome Sunroof Surround**

Begin by prying the stock switch loose from the headliner. Use your fingernails and pry from one side only.



Once the switch is removed from the headliner, disconnect the connector from the switch. Pry with your fingernails in the direction of the arrow and use your other hand to pull the switch away from the connector.



Replace the black plastic trim with the chrome trim piece. Push the switch outwards through the black trim. The chrome trim installs the same way in reverse.



If you want your sunroof switch to light up, now is the time to make the mod. Use BMW pin removal tool 88 88 6 611 132. This tool retails for \$35.50 from your BMW dealer. Or you can use an awl.



To make the switch light up, switch the positions of the green and black wires and also the brown and red wires. Make sure the ignition and lights are turned off before you de-mate or mate any connections. There is a small door inside the connector that opens to allow 2 of the connectors to come out. This door isolates the connectors and prevents electrical shorts.

At this point, you can re-mate the connector and your chrome sunroof switch. Turn ignition to position 2 and verify operation.